



1. Drill four holes for concrete anchors.
2. Fill holes with epoxy and attach base with  $\frac{1}{2}$ " concrete anchors. (Be sure to attach mount with tabs running parallel to wall. This will allow Trex brackets to be attached without screws striking mount. See Fig. A).
3. Sleeve Trex post over mount. Plumb post.
4. Secure Trex post to steel mount with self-tapping screws to ensure post does not move. (Tip: if desired, paint heads of self-tapping screws to match fence post).

**Specifications:**

- 14 ga. galvanized steel tower;  $\frac{3}{8}$ " base
- Four  $\frac{1}{2}$ " concrete anchors
- Coating thickness: G30-G90

*Disclaimer:* Measurements may vary slightly. Before mounting, use the actual base as a template for correct hole placement.

